













# Ulti-Line Plain Tile Vents

## Fixing Instructions

### Ulti-Line Plain Tile Vent

	<p><b>1</b></p> <p>Decide position where vent is to be installed, cut and mark membrane</p>
	<p><b>2</b></p> <p>Fold Envelope section of the Membrane over the top batten and secure into position</p>
	<p><b>3</b></p> <p>Select vent colour to suit and if being used for extraction also select adaptor ULTI3PTVA and flexipipe ULTI3FP. Do not fix adaptor at this time</p>
	<p><b>4</b></p> <p>Position vent in the roof secure to the batten and if adaptor needed fit this from the underside</p>
	<p><b>5</b></p> <p>Start to lay tile around the vent ensure that these are nailed in line with the Tile manufacturers recommended nail size</p>
	<p><b>6</b></p> <p>Complete the roof and when finished you will have the Ulti-Mate Plain Tile Vent installation completed</p>

### Ulti-Line Plain Tile Ulti-Match Vent

	<p><b>7</b></p> <p>Identify where Ulti-Match Vent is to be fitted as also ideal for "retro fit" on old or obsolete tiles</p>
	<p><b>8</b></p> <p>Expose the area where the vent is to be fitted and follow point 1 &amp; 2 on cutting and fixing the membrane</p>
	<p><b>9</b></p> <p>Position the Vent and cut two matching tile 75mm in length ready to adhere to the Ulti-Match Vent.</p>
	<p><b>10</b></p> <p>Use a suitable Sealant (must adhere to ASA Plastic and finish of Tile), apply cut tile to Vent.</p>
	<p><b>11</b></p> <p>Once Cut sections of Tile are adhered run a sealant strip on top edge and then allow sealant to fully adhere</p>
	<p><b>12</b></p> <p>Complete the roof and if required fit the adaptor ULTI3PTVA and flexipipe ULTI3FP to the underside of the Vent</p>



All products are covered by our 15 year Durability Warranty terms and conditions can be found on our website.



All plastic products are made in UK.